


TCC Accumulator Spring

Part No.
44912-01

Springs (5)

Chrysler 45RFE, 545RFE, 65RFE, 66RFE, 68RFE



1. Disassembly

- Remove OE accumulator retainer, spring and valve.
- Discard spring, while keeping valve and retainer for reuse.
- Ensure all broken spring pieces are removed.

2. Installation & Assembly

- Inspect valve and bore for wear or damage from broken spring.
- Insert Sonnax spring into valve and install into accumulator bore.
- Secure with OE valve retainer.